

BARSTOOL - 12466

PARTS LIST :

A1 WOODEN BAR 1PC

1PC



A2 WOODEN BAR BACKREST 1PC

1PC



B. WOODEN STEP 1PC

1PC



C. CHAIR BACKREST 1PC

1PC



D. CHAIR LEG 2 PCS

2 PCS



E. CHAIR SEAT 1PC

1PC



HARDWARE :

F1 WOODEN DOWELS $\phi 6$ mm 16 PCS

16 PCS



F2 WOODEN DOWELS $\phi 10$ mm 2 PCS

2 PCS



NOTE : Use a soft mallet hammer (not included) to prevent marking or denting wood when inserting wood dowels. Do not use excessive force to insert dowels. After inserting wood dowels, minimal sanding may be necessary to make dowel ends flush with surface.

