


NEXUS DINING TABLE (15102)

Assembly Instructions



15102



A

1 pc tabletop



B

1 pc metal plate




C

1 pc Allen key



D

28 pcs bolt M6 x 20 mm



E

2 pcs leg frames




F

1 pc bolt M6 x 55 mm




WESTMINSTER TEAK

STEP 1




Remove the bolts from the bottom of the tabletop with the Allen key (C) provided to detach the metal plate from the seat. This will be reattached onto the seat in Step 4.

STEP 2




Place the set of legs (E), one over the other in a criss-cross manner as shown. Lock them into place using bolt (F).

STEP 3




Once the legs are secured, place the metal plate (B) over the top of the legs (as shown) and attach it with the bolts (D) using the Allen key.

STEP 4



Place the table top on the floor with the bottom facing up and bolt the legs onto the tabletop as shown. Use the same bolts (D) that were removed earlier from Step 1 to attach the assembled legs to the tabletop.



FOR ASSEMBLY REFERENCE.