

# 15916 SURF ROUND DINING TABLE

PART LIST :

A. TABLE TOP = 1 PCS

B. LEGS = 4 PCS

HARDWARE :

C. WASHER

D. BOLT

E. ALLEN KEY

F. WOODEN PLUG

: = 12 PCS

: = 16 PCS

: = 1 PC

: = 1 PC

